



HOTEL & HOME SAFE



Sherni Enterprises, Gat No. 1616, Rainbow Warehousing, Keshnand Phata, Wagholi Village, Pune - 412207.
Tel : +91 20 40027683 / 27052336 Email : kutar@airtelmail.in, kutar@vsnl.com Website : www.shernienterprises.com

DELTA SAFE

Home and Hotel Safe marketed by Sherni Enterprises under DELTA brand has unique features and excellent design. Safe is fitted with motorized Solenoid which is not commonly used in other Safes. Opening and closing the Safe with Handle makes the lock mechanism simple and trouble free.

DELTA Safes are thoughtfully designed in various different sizes to suit the end users.

DELTA Safes are so competitively priced that every class of family can afford to fit in their homes, may it be a bungalow or a flat.

For Hotel Industries which is a mandatory requirement cannot get a better deal in terms of pricing and variance in size. We look forward to you having comfortable and secured life.

DELTA HOME AND HOTEL SAFES

Unit dimension (HxWxD mm)	Description	Reference picture
300x220x110	Body is 2mm steel; Door front material is 3mm steel.	
367x314x117	Body is 2mm steel; Door front material is 3mm steel; One steel shelf.	
200x520x370	Body is 2mm steel; Door front material is 2mm steel.	
250x350x250	Body is 2mm steel; Door front material is 4mm steel; One steel shelf.	
300x380x300	Body is 2mm steel; Door front material is 4mm steel; One steel shelf.	
500x350x330	Body is 2mm steel; Door front material is 4mm steel; Two steel shelves.	



SAFE OPERATING INSTRUCTIONS

PLEASE LEAVE SAFE IN OPEN CONDITION WHEN CHECKING OUT OF ROOM

INSTRUCTIONS FOR OPERATING THE SAFE

Step 1 Press the **Red Button** located behind the door, near the Hinge. You will hear a beep and yellow light of the keypad will remain on for 30 seconds.

Step 2 Enter new desired Combination (between 4-8 digits), then press # or *. It will beep and the yellow light will go off indicating the new combination is set successfully.

Step 3 Before you close the door try the new combination code followed by # or * several times to make sure that the locking mechanism works. **DO NOT shut the door until you have confirmed that your new combination code has been entered correctly**

Step 4 In order to open the Safe in the future enter the Combination Code you have set followed by # or * button and turn the knob.

1. If the incorrect Combination code is entered 3 times you will have an automatic lockout for 20 seconds before you can try your code again.
2. If the incorrect code is entered 3 additional times there will be a 5 minute lockout before the code can be tried again.

Note: In case of any problem with the operation of the Safe, kindly contact Reception or Housekeeping Department of the Hotel.



HOTEL SAFE MANUAL

OPERATING DELTA SAFE WITH MASTER COMBINATION

Step 1:

Instructions to open the Safe:

1. When you first receive your Electronic Safe you will need to open the door with the key in order to install the batteries. Batteries are inside the Safe in the hardware bag.
2. To open the door with the key, first remove the small central panel located in front of the Safe. Insert the key and turn counterclockwise. Turn the knob to the right and open the door.

Note: This key has been provided (in duplicate) in case you lose or forget your Master Combination code or the batteries run low. DO NOT lose the key as NO replacement will be made. In this event, the only choice would be to break open the Safe.

3. Open the battery compartment located on the back of the door by pushing the tab in the direction of the arrow and install the batteries.

Step 2:

Instructions to Change the Master Combination:

Note: The Safe has been preset with the Master Combination at 9999 # or *

1. To change master combination, with the door open, Press '0' two times (00).
2. Press and release the Red Button located adjacent to the battery slot. You will hear a beep and the yellow light on the front of the Safe will remain on for 30 seconds for you to change the code.
3. Set the new desired Master Combination (between 4-8 digits), then press # or *. It will beep and the yellow light will go off indicating the new combination is set successfully.
4. Before you close the door try the new combination code followed by # or * several times to make sure the locking mechanism is operating.
5. In order to open the Safe in the future enter the Master Combination you have set followed by # or * and turn the knob.

Note: DO NOT SHUT THE DOOR UNTIL YOU HAVE CONFIRMED THAT YOUR NEW COMBINATION CODE HAS BEEN ENTERED CORRECTLY.

(P.T.O)



In case of entering an Incorrect Security code

1. If the incorrect security code is entered 3 times you will have an automatic lockout for 20 seconds before you can try your code again.
2. If the incorrect security code is entered 3 additional times there will be a 5 minute lockout before the code can be tried again.
3. Always remember you can unlock the Safe manually at any time with the help of the keys provided.

BATTERY REPLACEMENT

- This Safe uses 4-AA batteries. Under normal use, batteries will last about 1 year.
- When the battery is low, a red light will flash.
- To replace the batteries, open the battery compartment on the back of the door by pushing the tab in the direction of the arrow and install new batteries.
- If set program is lost reprogram your combination code after you replace the batteries. (See steps provided under 'Instructions to change Master Combination').

MAINTENANCE OF THE SAFE

If the door of the Safe starts to rub on the door frame - tighten the threaded stem located near the door hinges (Use an Allen Wrench to tighten stem). This will help realign the door and give you trouble free access to the contents of your Safe.

SECURING THE SAFE

- Secure the Safe to the wall and/ or on permanent shelf by fixing screws through the holes provided inside the Safe.
- Secure the Safe with the fasteners made available.

Note: The Safe needs to be upright and right side up or the locking mechanism will not function properly.

Important Instructions:

- Keep a record of your Master combination code in a secure place.
- Keep keys provided in a secure place.
- DO NOT STORE KEYS OR COMBINATION INSIDE SAFE.

SHERNI LOCKS MANUFACTURERS PVT. LTD.

GAT NO. 1343, AHURA WAREHOUSING, CHOKHI DHANI ROAD, NEAR BIRLA CEMENT FACTORY, OFF NAGAR ROAD, WAGHOLI, PUNE 412 207







TEL NO. +91 955243876

E-mail : kutar@shernilocks.com

Website: www.shernilocks.com

DELTA HOME AND HOTEL SAFES

JULY 01, 2018

Sr. No.	Unit dimension (HxWxD mm)	Description	Reference picture
1	LAG 500 300x220x110 12" X 8.5" X 4.5" Wt.: 6 Kgs.	Body is 2mm Door is 3mm	
2	LAG505 367x314x117 14.5"X 12.5" X 4.5" Wt.: 9 Kgs.	Body is 2mm Door is 3mm One shelf.	
3	LAG508 200x520x370 8" X 20.5" x 14.5" Wt.: 15 Kgs.	Body is 2mm Door is 2mm	
4	LAG514 250x350x250 10" X 14" x 10" Wt.: 11 Kgs.	Body is 2mm Door is 4mm One shelf.	
5	LAG515 300x380x300 12" X 15" X 12" Wt.: 14 Kgs.	Body is 2mm Door is 4mm One shelf.	
6	LAG520 500x350x330 20" X 14" X 13" Wt.: 21 Kgs.	Body is 2mm Door is 4mm Two shelves.	

NOTE:

GST : 18% Extra .
 Payment : Against Order .
 Warrantee : One year from the date of Invoice
 Delivery : 2 to 3 weeks from the date of Order
 Transport : At cost

For further details visit our site: www.shernilocks.com